




Auxiliary Drying Unit

DU2-64

USER'S MANUAL



Thank you very much for purchasing this product.

- To ensure correct and safe usage with a full understanding of this product's performance, please be sure to read through this manual completely and store it in a safe location.
- Unauthorized copying or transferral of this manual, in whole or in part, is prohibited.
- The contents of this document and the specifications of this product are subject to change without notice.
- The documentation and the product have been prepared and tested as much as possible. If you find any misprint or error, please inform us.
- Roland DG Corp. assumes no responsibility for any direct or indirect loss or damage which may occur through use of this product, regardless of any failure to perform on the part of this product.
- Roland DG Corp. assumes no responsibility for any direct or indirect loss or damage which may occur with respect to any article made using this product.

Roland DG Corporation



1000010051

R1-130121

For the USA

FEDERAL COMMUNICATIONS COMMISSION RADIO FREQUENCY INTERFERENCE STATEMENT

NOTE:

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Unauthorized changes or modification to this system can void the users authority to operate this equipment.

Use only I/O cables that have been designed and manufactured specifically for this device.

For Canada

NOTICE

This Class A digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

AVIS

Cet appareil numérique de la classe A respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

For California

WARNING

This product contains chemicals known to cause cancer, birth defects and other reproductive harm.

For EU Countries



Manufacturer:

ROLAND DG CORPORATION

1-6-4 Shinmiyakoda, Kita-ku, Hamamatsu-shi, Shizuoka-ken, 431-2103 JAPAN

The authorized representative in the EU:

Roland DG EMEA, S.L.

Parc Tecnologic del Valles C/ Ceramistes, 6 08290 Cerdanyola del Valles / Barcelona Spain

NOTICE

Grounding Instructions

In the event of a malfunction or breakdown, grounding provides a path of least resistance for electric current to reduce the risk of electric shock. This tool is equipped with an electric cord having an equipment-grounding conductor and a grounding plug. The plug must be plugged into a matching outlet that is properly installed and grounded in accordance with all local codes and ordinances.

Do not modify the plug provided - if it will not fit the outlet, have the proper outlet installed by a qualified electrician.

Improper connection of the equipment-grounding conductor can result in a risk of electric shock. The conductor with insulation having an outer surface that is green with or without yellow stripes is the equipment-grounding conductor. If repair or replacement of the electric cord or plug is necessary, do not connect the equipment-grounding conductor to a live terminal.

Check with a qualified electrician or service personnel if the grounding instructions are not completely understood, or if in doubt as to whether the tool is properly grounded.

Use only 3-wire extension cords that have 3-prong grounding plugs and 3-pole receptacles that accept the tool's plug.

Repair or replace damaged or worn cord immediately.

For EU

WARNING

This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

Roland DG Corp. has licensed the MMP technology from the TPL Group.

Contents

Contents.....	1
⚠ To Ensure Safe Use.....	2
⚠ Pour utiliser en toute sécurité	7
Chapter 1 Introduction	13
1-1 About This Machine	14
What's the DU2-64?	14
Compatible Printers (As of March 2013).....	14
1-2 Part Names and Functions	15
1-3 Included Items.....	16
1-4 Installing on the Printer	17
Step1: Install the Drying-heater Unit	17
Step2: Install the Blower-fan Unit.....	20
1-5 Connecting the Cables.....	23
Connecting the Cables.....	23
Chapter 2 Operation	25
2-1 Operation of the Drying-heater Unit.....	26
What to Do First	26
Switching the Power On and Off	26
Making the Temperature Setting for the Drying-heater Unit.....	27
2-2 Operation of the Blower-fan	28
Switching the Blower-fan Unit On.....	28
Chapter 3 Appendix	29
3-1 What to Do If	30
The Drying-heater Unit Doesn't Get Hot	30
The Blower-fan Unit Doesn't Run	30
If a Message Appears	30
3-2 Locations of the Power Rating and Serial Number Labels	31
3-3 Specifications.....	32

Company names and product names are trademarks or registered trademarks of their respective holders.

Copyright © 2013 Roland DG Corporation

<http://www.rolanddg.com/>



To Ensure Safe Use

Improper handling or operation of this machine may result in injury or damage to property. Points which must be observed to prevent such injury or damage are described as follows.

About WARNING and CAUTION Notices

WARNING	Used for instructions intended to alert the user to the risk of death or severe injury should the unit be used improperly.
CAUTION	Used for instructions intended to alert the user to the risk of injury or material damage should the unit be used improperly. Note: Material damage refers to damage or other adverse effects caused with respect to the home and all its furnishings, as well to domestic animals or pets.

About the Symbols

	The symbol alerts the user to important instructions or warnings. The specific meaning of the symbol is determined by the design contained within the triangle. The symbol at left means "danger of electrocution."
	The symbol alerts the user to items that must never be carried out (are forbidden). The specific thing that must not be done is indicated by the design contained within the circle. The symbol at left means the unit must never be disassembled.
	The symbol alerts the user to things that must be carried out. The specific thing that must be done is indicated by the design contained within the circle. The symbol at left means the power-cord plug must be unplugged from the outlet.

Incorrect operation may cause injury

WARNING



Be sure to follow the operation procedures described in this documentation. Never allow anyone unfamiliar with the usage or handling of the machine to touch it.

Incorrect usage or handling may lead to an accident.



Keep children away from the machine.

The machine includes areas and components that pose a hazard to children and may result in injury, blindness, choking, or other serious accident.



Never operate the machine while tired or after ingesting alcohol or any medication.

Operation requires unimpaired judgment. Impaired judgment may result in an accident.



Never use the machine for any purpose for which it is not intended, or use the machine in an undue manner that exceeds its capacity.

Doing so may result in injury or fire.



For accessories (consumable items, power cord, and the like), use only genuine articles compatible with this machine.

Incompatible items may lead to an accident.



Before attempting cleaning, maintenance, or attachment or detachment of optional items, disconnect the power cord.

Attempting such operations while the machine is connected to a power source may result in injury or electrical shock.



Never attempt to disassemble, repair, or modify the machine.

Doing so may result in fire, electrical shock, or injury. Entrust repairs to a trained service technician.

CAUTION



Conduct operations in a clean, brightly lit location.

Working in a location that is dark or cluttered may lead to an accident, such as becoming caught in the machine as the result of an inadvertent stumble.



Keep the fingers and face away from the blower fan.

Fingers or hair may become entangled, resulting in injury.




Never climb or lean on the machine.

The machine is not made to support a person. Climbing or leaning on the machine may dislodge components and cause a slip or fall, resulting in injury.

Danger of electrical short, shock, electrocution, or fire

WARNING

-  **Connect to an electrical outlet that complies with this machine's ratings (for voltage, frequency, and current).**
Incorrect voltage or insufficient current may cause fire or electrical shock.



-  **Never use out of doors or in any location where exposure to water or high humidity may occur. Never touch with wet hands.**
Doing so may result in fire or electrical shock.

-  **Never allow any foreign object to get inside. Never expose to liquid spills.**
Inserting objects such as coins or matches or allowing beverages to be spilled into the ventilation ports may result in fire or electrical shock. If anything gets inside, immediately disconnect the power cord and contact your authorized Roland DG Corp. dealer.

-  **Never place any flammable object nearby. Never use a combustible aerosol spray nearby. Never use in any location where gases can accumulate.**
Combustion or explosion may be a danger.

-  **Handle the power cord, plug, and electrical outlet correctly and with care. Never use any article that is damaged.**
Using a damaged article may result in fire or electrical shock.

-  **When using an extension cord or power strip, use one that adequately satisfies the machine's ratings (for voltage, frequency, and current).**
Use of multiple electrical loads on a single electrical outlet or of a lengthy extension cord may cause fire.

WARNING

-  **Connect to ground.**
This can prevent fire or electrical shock due to current leakage in the event of malfunction.


-  **Position so that the power plug is within immediate reach at all times.**
This is to enable quick disconnection of the power plug in the event of an emergency. Install the machine next to an electrical outlet. Also, provide enough empty space to allow immediate access to the electrical outlet.

-  **If sparking, smoke, burning odor, unusual sound, or abnormal operation occurs, immediately unplug the power cord. Never use if any component is damaged.**
Continuing to use the machine may result in fire, electrical shock, or injury. Contact your authorized Roland DG Corp. dealer.


-  **When the machine will be out of use for a prolonged period, disconnect the power cord.**
This can prevent accidents in the event of current leakage or unintended startup.

-  **Do not use the supplied power supply cord for other products.**


 **Important notes about the power cord, plug, and electrical outlet**




Never place any object on top or subject to damage.




Never allow to get wet.




Never bend or twist with undue force.




Never make hot.



Never pull with undue force.



Dust may cause fire.



Never bundle, bind, or roll up.

⚠ Danger of fire or burns

⚠ WARNING




Caution: high temperatures

Areas such as the dryer become hot. Exercise caution to avoid fire or burns.

⚠ Warning Labels

Warning labels are affixed to make areas of danger immediately clear. The meanings of these labels are as follows. Be sure to heed their warnings. Also, never remove the labels or allow them to become obscured.



Keep the fingers and face away from the blower fan.

Fingers or hair may become entangled, resulting in injury.



Pour utiliser en toute sécurité

La manipulation ou l'utilisation inadéquates de cet appareil peuvent causer des blessures ou des dommages matériels. Les précautions à prendre pour prévenir les blessures ou les dommages sont décrites ci-dessous.

Avis sur les avertissements

! ATTENTION	Utilisé pour avertir l'utilisateur d'un risque de décès ou de blessure grave en cas de mauvaise utilisation de l'appareil.
! PRUDENCE	Utilisé pour avertir l'utilisateur d'un risque de blessure ou de dommage matériel en cas de mauvaise utilisation de l'appareil. * Par dommage matériel, il est entendu dommage ou tout autre effet indésirable sur la maison, tous les meubles et même les animaux domestiques.

À propos des symboles

	Le symbole attire l'attention de l'utilisateur sur les instructions importantes ou les avertissements. Le sens précis du symbole est déterminé par le dessin à l'intérieur du triangle. Le symbole à gauche signifie "danger d'électrocution."
	Le symbole avertit l'utilisateur de ce qu'il ne doit pas faire, ce qui est interdit. La chose spécifique à ne pas faire est indiquée par le dessin à l'intérieur du cercle. Le symbole à gauche signifie que l'appareil ne doit jamais être démonté.
	Le symbole prévient l'utilisateur sur ce qu'il doit faire. La chose spécifique à faire est indiquée par le dessin à l'intérieur du cercle. Le symbole à gauche signifie que le fil électrique doit être débranché de la prise.

L'utilisation incorrecte peut causer des blessures

ATTENTION

 **S'assurer de suivre les procédures d'utilisation décrites dans la documentation. Ne jamais permettre à quiconque ne connaît pas le fonctionnement ou la manutention de l'appareil de le toucher.** L'utilisation ou la manutention incorrectes peuvent causer un accident.

 **Garder les enfants loin de l'appareil.** L'appareil comporte des zones et des composants qui présentent un danger pour les enfants et qui pourraient causer des blessures, la cécité, la suffocation ou d'autres accidents graves.

 **Ne jamais faire fonctionner l'appareil après avoir consommé de l'alcool ou des médicaments, ou dans un état de fatigue.** L'utilisation de l'appareil exige un jugement sans faille. L'utilisation avec les facultés affaiblies pourrait entraîner un accident.

 **Ne jamais utiliser l'appareil à des fins autres que celles pour lesquelles il est conçu. Ne jamais l'utiliser de manière abusive ou d'une manière qui dépasse sa capacité.**

Le non-respect de cette consigne peut causer des blessures ou un incendie.

 **Utiliser uniquement des accessoires d'origine (accessoires en option, articles consommables, câble d'alimentation et autres articles semblables), compatibles avec l'appareil.**

Les articles incompatibles risquent de causer des accidents.

 **Débrancher le câble d'alimentation avant de procéder au nettoyage ou à l'entretien de l'appareil, et avant d'y fixer ou d'en retirer des accessoires en option.**

Tenter ces opérations pendant que l'appareil est branché à une source d'alimentation peut causer des blessures ou un choc électrique.

 **Ne jamais tenter de démonter, de réparer ou de modifier l'appareil.**

Le non-respect de cette consigne risque de provoquer un incendie, un choc électrique ou des blessures. Confier les réparations à un technicien ayant la formation requise.

PRUDENCE

 **Utiliser l'appareil dans un endroit propre et bien éclairé.** Travailler dans un endroit sombre ou encombré peut causer un accident; l'utilisateur risque, par exemple, de trébucher malencontreusement et d'être coincé par une partie de l'appareil.

 **Tenir les doigts et la tête loin du ventilateur soufflant.** Les doigts ou les cheveux pourraient être coincés ou s'emmêler, ce qui causerait des blessures.

 **Ne jamais grimper ni s'appuyer sur la machine.** La machine n'est pas conçue pour supporter le poids d'une personne. Grimper ou s'appuyer sur la machine peut déplacer des éléments et causer un faux pas ou une chute, ce qui causerait des blessures.


Risque de décharge ou de choc électrique, d'électrocution ou d'incendie

ATTENTION



Brancher à une prise électrique conforme aux caractéristiques de cet appareil (tension, fréquence et courant).

Une tension incorrecte ou un courant insuffisant peuvent causer un incendie ou un choc électrique.



Ne jamais utiliser à l'extérieur ni à un endroit où l'appareil risque d'être exposé à de l'eau ou à une humidité élevée. Ne jamais toucher l'appareil avec des mains mouillées.

Le non-respect de cette consigne risque de provoquer un incendie ou un choc électrique.



Ne jamais insérer d'objet étranger dans l'appareil. Ne jamais exposer l'appareil aux déversements de liquides.

L'insertion d'objets comme des pièces de monnaie ou des allumettes, ou le déversement de liquides dans les orifices de ventilation peuvent causer un incendie ou un choc électrique. Si un objet ou du liquide s'infiltre dans l'appareil, débrancher immédiatement le câble d'alimentation et communiquer avec le représentant Roland DG Corp. autorisé.



Ne jamais placer d'objet inflammable à proximité de l'appareil. Ne jamais utiliser de produit inflammable en aérosol à proximité de l'appareil. Ne jamais utiliser l'appareil dans un endroit où des gaz peuvent s'accumuler.

Une combustion ou une explosion pourraient se produire.

ATTENTION



Manipuler le câble d'alimentation, la fiche et la prise électrique correctement et avec soin.

Ne jamais utiliser un article endommagé, car cela pourrait causer un incendie ou un choc électrique.



Si une rallonge ou une bande d'alimentation électrique sont utilisées, s'assurer qu'elles correspondent aux caractéristiques de l'appareil (tension, fréquence et courant).

Ne jamais utiliser un article endommagé, car cela pourrait causer un incendie ou un choc électrique.



Mise à la terre.

La mise à la terre peut prévenir un incendie ou un choc électrique dus à une fuite de courant en cas de défaillance.



Placer l'appareil de façon à ce que la fiche soit facile d'accès en tout temps.

Ainsi, l'appareil pourra être débranché rapidement en cas d'urgence. Installer l'appareil près d'une prise électrique. En outre, prévoir suffisamment d'espace pour que la prise électrique soit facile d'accès.



S'il se produit des étincelles, de la fumée, une odeur de brûlé, un bruit inhabituel ou un fonctionnement anormal, débrancher immédiatement le câble d'alimentation. Ne jamais utiliser si un composant est endommagé.

Continuer à utiliser l'appareil peut causer un incendie, un choc électrique ou des blessures. Communiquer avec le représentant Roland DG Corp. Autorisé.



Si l'appareil doit rester inutilisé pendant une longue période, débrancher le câble d'alimentation.


Cela peut prévenir les accidents en cas de fuite de courant ou de démarrage accidentel.




Ne pas utiliser le cordon électrique fourni avec d'autres produits.

⚠ Pour utiliser en toute sécurité


⚠ Remarques importantes à propos du câble d'alimentation, de la fiche et de la prise électrique




Ne jamais déposer aucun objet sur le câble, sur la fiche ou sur la prise car cela risque de les endommager.




Ne jamais laisser l'eau toucher le câble, la fiche ou la prise.




Ne jamais plier ni tordre le câble avec une force excessive.




Ne jamais chauffer le câble, la fiche ou la prise.



Ne jamais tirer sur le câble ou la fiche avec une force excessive.



La poussière peut causer un incendie.



Ne jamais plier ni enruler le câble.

⚠ Risque d'incendie ou de brûlures

⚠ ATTENTION




Attention : températures élevées.

Les zones comme le séchoir chauffent. Faire preuve de prudence pour éviter un incendie ou des brûlures.

⚠ Vignettes d'avertissement

Des vignettes d'avertissement sont apposées pour qu'il soit facile de repérer les zones dangereuses. La signification des vignettes est donnée ci-dessous. Respecter les avertissements. Ne jamais retirer les vignettes et ne pas les laisser s'encrasser.



Attention : Température élevée
La platine et la surface de séchage chauffent. Être prudent pour éviter un incendie ou des brûlures.



Tenir les doigts et la tête loin du ventilateur soufflant.
Les doigts ou les cheveux pourraient être coincés ou s'emmêler, ce qui causerait des blessures.

Chapter 1

Introduction

1-1 About This Machine

What's the DU2-64?

This is an auxiliary drying unit that combines a drying-heater unit and a blower-fan unit. It uses the drying-heater unit to dry the ink by warming the media after printing. It also uses the blower-fan unit to dry the ink by blowing air against the surface of the media.


An electrical outlet separate from that for the printer is required in order to use the drying unit.

Compatible Printers (As of March 2013)

XF-640

- The printer and the drying-heater unit require separate high-amperage electrical outlets. Connect the two power cords to outlets on separate systems. Also, make sure that the electrical outlets meet the machine's ratings.

1-2 Part Names and Functions











Panel Notation

In this document, the keys on the operation panel for the printer are indicated by the following images.

	Cursor keys
	SETUP key
	ENTER key
	HEATER key

1-3 Included Items

		
Drying-heater unit (1)	Blower-fan unit (1)	Arms (one for right and left each)
		
Stays (one for right and left each)	Bolts (14)	Washers (4)
		
Bushing (1)	Cable clamps (4)	Hexagonal wrench (1)
		
Power cord (1)	User's Manual (this document) (1)	

1-4 Installing on the Printer

Step1: Install the Drying-heater Unit


⚠WARNING Perform this task with all power switches left switched off.
Otherwise sudden movement of the machine may cause injury.

1. Attach the arms.


- ① Referring to the figure below, assemble the right and left arms.

After tightening the bolts temporarily, tighten them completely (Two bolts for each arm).


There is no right/left distinction in arm assembly parts; however, arms assembled for right or left side are treated as right or left arms, respectively.




- ② Remove two bolts from each of the positions shown in the figure.



- ③ Attach the arms with the bolts removed in step ②.




- ④ Attach the bushing and cable clamp to the arm (right).



2. Install the drying-heater unit.


- ① Place the drying-heater unit on the arms.

Place it oriented as shown in the figure.




② Temporarily secure the drying-heater unit.

Temporarily attach the drying-heater unit to the arms with two bolts each on the right and left sides.



③ Secure the drying-heater unit in place.

Raise the drying-heater unit to eliminate the gap between the unit and the printer, and completely tighten the four bolts.



Step2: Install the Blower-fan Unit




WARNING Perform this task with all power switches left switched off.
Otherwise sudden movement of the machine may cause injury.

- ① Remove the cover L and R.


Push the part of figure below until it engage with an audible click.



Lift the cover in the direction of ①, and then pull it out in the direction of ②.




- ② Attach the stays.

The stays for the left and right are different. Attach them in the orientation shown in the figure.




③ Install the blower-fan unit.**④** Attach the bushing to the arm (right).

- ⑤ Attach two cable clamps at the location shown in the figure.



- ⑥ Attach the cover L and R.

① Hung cover on the hook of the printer and pull down in ② direction.
Push the part of figure below until it engage with an audible click.



1-5 Connecting the Cables

Connecting the Cables

⚠WARNING

Connect to an electrical outlet that complies with this machine's ratings (for voltage, frequency, and current).

Incorrect voltage or insufficient current may cause fire or electrical shock.

⚠WARNING

Connect to ground.

This can prevent fire or electrical shock due to current leakage in the event of malfunction.


⚠WARNING

Perform this task with all power switches left switched off.

Otherwise sudden movement of the machine may cause injury.

Connect the cables for the drying-heater unit and the blower-fan unit, and the power cord.

The printer and the drying-heater unit require separate high-amperage electrical outlets. Connect the two power cords to outlets on separate systems. Also, make sure that the electrical outlets meet the machine's ratings.



Chapter 2

Operation

2-1 Operation of the Drying-heater Unit

What to Do First

When you've finished installing this unit, set the printer's [OPTION DRYER] menu item to "ENABLE." Unless this is set to "ENABLE," turning on the power switch for the drying-heater unit doesn't make the temperature of the drying-heater unit rise.

Procedure

- ① Press .
- ② 
Press  several times to display the screen shown on the left.
Press .
- ③ 
Press  several times to display the screen shown on the left.
Press .
- ④ 
Use   to select "ENABLE."
Press .
- ⑤ Press   in this order to go back to the original screen.


Removing this unit

Before removing this unit, use the procedure described to set the [OPTION DRYER] menu item to "DISABLE," and turn off the power switch.

Switching the Power On and Off

The power switch for the drying-heater unit is found at the location shown in the figure. You use the power switch for ordinary switching of the power on and off.

When you've finished performing printing, turn off the power switch.



Making the Temperature Setting for the Drying-heater Unit

The temperature of the drying-heater unit is always set at the same temperature as the dryer on the printer. To change the temperature of the drying-heater unit, adjust the temperature of the dryer on the printer.

Procedure

- ① Press  .
- ②

PRE	35	PRINT	35
DRY	50		

 The present temperature is displayed.
- ③ Press  a second time.
- ④

DRYER	50	▲▼
	50	▶ 50 ▲

 Press  two times to select [DRYER].
- ⑤

DRYER	50	▲▼
	50	▶ 55 ▲

 Use   to enable the setting.
Press .
- ⑥ Press   in this order to go back to the original screen.

2-2 Operation of the Blower-fan

Switching the Blower-fan Unit On

The blower-fan unit has no power switch. You switch the blower-fan unit on and off via settings made on the printer. When you're using the blower-fan unit, set the printer's [BLOWER FAN] menu item to "ENABLE." When this menu item is set to "ENABLE," the blower fan comes on at the same time when printing starts. When printing ends, the blower fan stops automatically.

Procedure

- ① Press  .
- ② 
Press  several times to display the screen shown on the left.
Press .
- ③ 
Press  two times to display the screen shown on the left.
Press .
- ④ 
Use   to select "ENABLE."
Press .
- ⑤ Press   in this order to go back to the original screen.

Removing this unit

Before removing this unit, use the procedure described to set the [BLOWER-FAN] menu item to "DISABLE," and turn off the power switch.

Chapter 3

Appendix

3-1 What to Do If

The Drying-heater Unit Doesn't Get Hot

Is the power cord connected?

Connect the power cord for the drying-heater unit securely.

☞ P. 23, "Connecting the Cables"

Is the drying-heater unit cable connected?

Connect the drying-heater unit cable to the printer unit.

☞ P. 23, "Connecting the Cables"

Is [OPTION DRYER] on the printer set to "ENABLE" as its value?

The drying-heater unit doesn't operate unless this is set to "ENABLE." Check the setting.

☞ P. 26, "What to Do First"

Is the power switch on?

Make sure the power switch is on.

☞ P. 26, "Switching the Power On and Off"

Is the temperature of the room too low?

Use the machine in an environment where the temperature is 20 to 32°C (68 to 90°F).

The Blower-fan Unit Doesn't Run

Is the blower-fan unit cable connected?

Connect the blower-fan unit cable to the printer unit.

☞ P. 23, "Connecting the Cables"

Is [BLOWER FAN] on the printer set to "ENABLE" as its value?

The blower-fan unit doesn't operate unless this is set to "ENABLE." Check the setting.

☞ P. 28, "Switching the Blower-fan Unit On"

If a Message Appears


[OPTION-DRYER IS NOT CONNECTED]

The unit is not connected correctly. Switch off the power to all devices, then check the connection to the unit.

☞ P. 23, "Connecting the Cables"

☞ P. 26, "What to Do First"

3-2 Locations of the Power Rating and Serial Number Labels



Power Rating

Use an electrical outlet that meets the requirements for voltage, frequency, and amperage given here.

Serial Number

This is required when you seek maintenance, servicing, or support. Never peel off the label or let it get dirty.

3-3 Specifications

	DU2-64
Dryer unit	Heating type (with blower fan), setting range for the preset temperature: 30 to 55°C (86 to 130°F) (*1)
Power requirements (*2)	AC 100 to 120V ±10%, 5.5 A, 50/60 Hz or AC 220 to 240 V ±10%, 3 A, 50/60 Hz
Power consumption	Approx. 750 W
Weight	26 kg (57 lb.)
Environment	Power on (*3)
	Temperature: 15 to 32°C (59 to 90°F) -- (20°C (68°F) or more recommended), humidity: 35 to 80% (no condensation)
Included items	Power off
	Temperature: 5 to 40°C (41 to 104°F), humidity: 20 to 80% (no condensation)
Included items	
Power cord, arms, bushing, cable clamps, stays, hexagonal wrench, bolts, washers, User's Manual	

*1


- Warm-up is required after powerup. This may require 5 to 20 minutes, depending on the operating environment.
- Depending on the ambient temperature and media width, the preset temperature may fail to be reached.

*2

- Be sure to connect the machine to an unshared electrical circuit.
- Be sure to verify the amperage of the circuit breaker or fuse used.

*3

- Operating environment



*4

When this unit is used with a printer equipped with a cutting feature, no assurance is made with respect to the following points. Refer also to the user's manual included with the printer.

- Distance accuracy (when cutting)
- Repetition accuracy (when cutting)
- Repetition between printing and cutting
- Alignment accuracy for printing and cutting when reloading media

For China

产品中有毒有害物质或元素的名称及含量

部件名称	有毒有害物质或元素					
	铅(Pb)	汞(Hg)	镉(Cd)	六价铬(Cr(VI))	多溴联苯(PBB)	多溴二苯醚(PBDE)
印刷电路板	×	○	×	○	○	○
头部	×	○	○	○	○	○
壳体、底架	×	○	○	○	○	○
电源	×	○	×	○	○	○
其他(电缆、附件等)	×	○	○	○	○	○

○：表示该有毒有害物质在该部件所有均质材料中的含量均在 GB/T26572-2011 标准规定的限量要求以下。

×：表示该有毒有害物质至少在该部件的某一均质材料中的含量超出 GB/T26572-2011 标准规定的限量要求。

环保使用期限



此标志适用于在中国国内销售的电子信息产品，表示环保使用期限的年数。所谓环保使用期限是指在自制造日起的规定期限内，产品中所含的有害物质不致引起环境污染，不会对人身、财产造成严重的不良影响。

环保使用期限仅在遵照产品使用说明书，正确使用产品的条件下才有效。

不当的使用，将会导致有害物质泄漏的危险。

For EU Countries



This product must be disposed of separately at your local waste recycling center. Do not dispose of in household waste bin.



Lever dit product in bij een lokaal afvalverzamelpunt. NIET met normaal huishoudelijk afval afvoeren.



Bitte führen Sie dieses Produkt separat Ihrer örtlichen Entsorgungsstelle zu. Bitte nicht mit dem normalen Hausmüll entsorgen.



Dette Produkt skal smides særskilt væk på den lokale affalds- og genbrugsstation. Må ikke smides ud sammen med almindeligt husholdningsaffald.



Ne jetez pas le produit avec vos ordures ménagères. Portez-le dans un centre recyclage des déchets.



Täta tuotetta ei saa hävittää normaaliien talousjätteiden mukana, vaan se on toimitettava ongelmajätteiden keräilypisteesseen hävitettäväksi.



Questo prodotto deve essere smaltito negli appositi contenitori per la raccolta differenziata, non buttare nel cestino dei rifiuti casalinghi.



Produkten måste kasseras separat på din lokala återvinningscentral. Släng inte produkten tillsammans med hushållssoporna.



Este producto debe devolverse al centro de reciclaje más cercano a su domicilio para su correcta eliminación. No lo tire a la basura.



Mην πετάξετε το αντικείμενο αυτό στο καλάθι των απορριμμάτων. Αφαιρέστε τις μπαταρίες και προσκομίστε το στο τοπικό κέντρο ανακύκλωσης.



Deite fora separadamente este produto no seu centro de reciclagem local. Não o deite fora no seu caixote do lixo.

